ROHL
Authentic Luxury for Kitchen and Bath®

PERRIN & ROWE®
MAYFAIR LONDON

www.rohlhome.com

Installation Instructions

PERRIN & ROWE
MAYFAIR LONDON

**The Triflow Kitchen Collection**

**Filter Installation Guide**

**• U.1812 Triflow Filter Fitted with U.1802 filter**




**• U.1816 Pre-Filter Fitted with U.1620 filter**



**Temp Range:**
Max 85°C/185°F

**Recommended Working Pressure:**
Min 1.7bar/25psi
Max 5bar/75psi

ROHL
Authentic Luxury for Kitchen and Bath®

**Please register your new product.**
**Complete the enclosed registration card, or call Toll free on 800.777.9762.**

ROHL
Authentic Luxury for Kitchen and Bath®

PERRIN & ROWE®
MAYFAIR LONDON

www.rohlhome.com

# Installation Instructions

## 5



Turn on the main supply valve.
Run the filtered water for 2 minutes to flush the system, and carefully check the system for leaks. The system is now ready for use.

For optimum filter performance when using the U.1802 filter cartridge use the stop valve to set a water flow of 0.4gpm to 0.5gpm max.

## 6 To Winterize the Unit



Shut off mains supply. A stop valve was supplied with the system for this purpose, and will be located on the adjacent pipe work.

If you plan to be away from home for extended periods, carry out the procedures above, to prevent the risk of freezing. Freezing will invalidate the warranty.

Turn the filtered lever on the faucet to the on position. This will confirm the water supply is off, and release the pressure in the system.

## 7 Pre-filter Installation




If installing a Pre-filter follow steps 1-3 for the second bracket taking into account the hose length supplied from the Pre-filter to the filter.

## 8




Tighten the hoses from the stop valve to the housings following the flow of the water shown on the cap. When installing the Pre-filter the system flows from the stop valve to the Pre-filter and on to the filter housing and then up to the filter tap.

## IMPORTANT NOTES

Do not use with water, that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system. Systems certified for cyst reductions may be used on disinfected waters that may contain filterable cysts.

Please ensure that the installation complies with applicable State & local plumbing codes.

System is to be supplied with cold water only.

## CARE & MAINTENANCE

Wipe down after use to avoid water spotting and mineral build up.

ROHL
Authentic Luxury for Kitchen and Bath®

PERRIN & ROWE®
MAYFAIR LONDON

www.rohlhome.com

# Installation Instructions

The Perrin and Rowe Collection
Filter Installation Guide

Congratulations on the purchase of your Perrin and Rowe/Triflow filtration Product. Correctly installed and with sensible care, this product will give you many years of trouble free service.

**IMPORTANT INFORMATION**

**These are instructions for Triflow filters and the optional add on pre-filter version of the model you are installing. Please read carefully to ensure correct installation.**

**Before you proceed... We recommend you engage the services of a registered plumber to install this product.**

**In addition to the guide below it is essential that the written information overleaf is carefully read and understood.**

## Preparation for Installer

☐ Flush the plumbing system before installing the Kitchen product.

☐ Ensure you have the correct fittings to connect to the filter faucet

**1**

ø3/8"
Main Cold Feed



Flow Direction

Install the supplied stop valve in an easily accessible area to allow access to turn off the water supply in the future, for servicing and cartridge replacement.




Position the filter housing leaving room around it for future access and cartridge replacement. Mark the screw holes ready for pilot holes. Leave room for the Pre-filter housing if necessary.

**2**

Flow direction

Check the hose length for distance






Drill the pilot holes and screw the filter housing bracket in position. Making sure to keep as level as possible.

Remember to leave room for servicing the cartridge on both housings.

**3**

**Flow direction**




Tighten the hoses from the stop valve to the housings following the flow of the water shown on the cap.

If installing a Pre-filter the system flows from the stop valve to the Pre-filter and on to the filter housing and then up to the filter tap.

**4**




With the supplied connector kit connect the hose from the filter housing to the filter tap using one of the connectors.

ROHL
Authentic Luxury for Kitchen and Bath®

3 Parker
Irvine, CA 92618
800-777-9762
www.rohlhome.com

ROHL
Authentic Luxury for Kitchen and Bath®

PERRIN & ROWE®
MAYFAIR LONDON

www.rohlhome.com

# Installation Instructions

**ROHL WARRANTY POLICY**

All products supplied by ROHL carry warranties against manufacturing defects.

Triflow products carry a Limited Lifetime Warranty.

ROHL LLC will provide free of charge, as its options, replacement part(s) or product (or a comparable alternative product) to replace those which have proven defective in materials or workmanship.

For full ROHL LLC WARRANTY please contact ROHL or visit www.rohlhome.com

## SPARES




ROHL
Authentic Luxury for Kitchen and Bath®

The U.1812 Inline Filter System has been tested & certified by the Water Quality Association according to NSF/ANSI 42 & 53 for the performance claims as verified and substantiated by the test data.

TESTED AND CERTIFIED Water Quality UNDER INDUSTRY STANDARDS

**Cartridge Service**

ROHL
3 Parker
Irvine, CA 92618
800-777-9762
www.rohlhome.com

Katadyn

Katadyn of Switzerland
Exclusive manufacturers of the FRX02 Filter Cartridges for Triflow

Perrin and Rowe is a registered trademark of TCL Ltd.

9001816U Issue 6